

Tumbler Click Clock™

It's not just any alarm clock

Quick User Manual



gingko
DESIGN - QUALITY - TIME

Tumbler Click Clock™

It's not just any alarm clock



Thank you for purchasing the Gingko Tumbler Click Clock.

Please read the instruction manual carefully to achieve the best performance of this product. For any further queries, please get in touch with us at support@gingkodesign.co.uk.

Please keep this manual safe for future reference.

PRODUCT FEATURES

1. Sound activated or permanent Clock display
2. Tumbling snooze alarm feature
3. Powered by in-built long lasting rechargeable battery.

PRODUCT CHARGING INSTRUCTION


1. Please charge the product before first time use with the micro USB cable provided
2. The USB 5V charging port is at the bottom of the clock and please connect the USB charging cable to any USB charging adapter to charge the product as long as its output is not more than 5V. See image below shown.
3. When charging, the indication light will be in red and turn to green when fully charged.

WARNING: Please DO NOT use any USB adapter which is more than 5V output to charge the product as this may eventually damage this product or shorten the battery life-span.


PRODUCT TOUCH BUTTON INTRODUCTION

Long touch: 3-5 seconds; Short Touch: 0-1 second

HR/MIN: a long touch to access to the time setting and short touch to change hour or minute number (after accessed to the time setting)

 : a long touch to access to the alarm setting menu and a short touch to confirm and exit the setting.

V/S: a long touch to change the time format between 12H format and 24H format and a short touch to change clock in sound activated display or permanent display.

 : Long touch to turn on or turn off the clock




PRODUCT OPERATING INSTRUCTION



- Product Power ON/OFF

A long touch on the power button  will turn on or turn off the clock.

- Time Setting

1. A long touch on the **HR** or **MIN** button for 3-5 seconds until a beep to access to the time setting mode and both hour or minute numbers on the display screen will flash.
2. touching the **HR** or **MIN** button to adjust the hour or minute number; the number will scroll up fast if you leave your finger on the touch button. Please note the number can only be scrolled up and can't be scrolled down.
3. After the preferred hour and minute is set, a short touch on the alarm button  will confirm and exit the setting.

- Alarm Setting

1. A long touch on the  button for 3-5 seconds until a beep to access to the alarm setting mode and both alarm hour or minute numbers on the display screen will flash.
2. Follow the same way as above to set up your preferred alarm hour and minute and confirm/exit the setting. When the alarm is set, there will be a dot displaying at the right bottom on the display screen.
3. To turn off the alarm, a long touch on the alarm button  and the clock will display **OFF** or you can simply flip the clock over and have the display screen facing down table.

- Sound Activated or Permanent Display Setting

This clock can be set on sound activated display or permanent display. When in sound activated display, the LED display will automatically switch off when the room is quiet and only light up again with an instant touch, tap or a click of your fingers. When in permanent display, the LED display will stay on all the time without going off. But in this setting, the battery would run out much faster than in sound activated display.

1. A short touch on the **V/S** button when the clock is normal time display mode, then the clock should either display **on:Sd** or **- - Sd**
on: Sd stands for sound activated display
- -: Sd stands for permanent display.
2. A short touch on the **V/S** button to select the display mode you prefer.

- 12H or 24H Time Display Format Setting

1. When the clock in time display mode, a long touch on the **V/S** button will change the time display format between 12 hour format and 24 hour format.
2. When the clock in 12 hour display format, there will be a dot displaying at the left top of the display screen, when the clock shows a PM time.

- Clock Snooze Instruction

1. To snooze when the alarm goes off, a gentle push of the tumbler click clock should make the clock snooze for 5 minutes and it can be snoozed for 5 times in total.
2. To stop the snooze, simply flip over the clock and have the display screen facing down the table.

PRODUCT CARE & WARRANTY

1. This product is made of natural solid wood and it's NOT recommended to place at any humid space such as a steaming room or humid or wet bath room.
2. Any drop from a high table or shelf could seriously damage the clock. Please place it at a safe table surface.
3. Please do not use any USB charging adapter which is more than 5V output to charge the product as it may eventually damage the battery and shorten its battery life-span. This may also invalidate your manufacturer warranty.
4. A natural wood grain on this product is perfectly normal because it is made of 100% natural wood. We do not accept such faulty claim because of the natural wood grain.
5. Do not disassemble this product without manufacturer instruction as this may damage this product and invalidate your manufacturer warranty.
6. Any damage caused by user error such a drop etc is not covered by our warranty policy.
7. The product comes with one year manufacturer warranty, to registered your warranty, please go to www.gingkodeign.co.uk

Tumbler Click Clock™

Quick User Manual



To discover more unique and elegant Gingko Design, please visit

www.gingkodesign.co.uk

Copyright © Gingko Design Ltd

All rights are registered and protected
Alle Rechte sind eingetragen und geschützt
Todos los derechos están registrados y protegidos

support@gingkodesign.co.uk
Printed in China

